

libORFA — PC-side gate library for Open Robotics Firmware Architecture

Создано системой Doxygen 1.5.9

Wed Aug 12 19:50:59 2009

Оглавление

1 Список задач	1
2 Алфавитный указатель групп	3
2.1 Группы	3
3 Дерево директорий	5
3.1 Алфавитный указатель директорий	5
4 Алфавитный указатель структур данных	7
4.1 Структуры данных	7
5 Список файлов	9
5.1 Файлы	9
6 Группы	11
6.1 Introspection	11
6.1.1 Функции	11
6.1.1.1 orfa_free_drivers	11
6.1.1.2 orfa_get_drivers	11
6.1.1.3 orfa_get_drivers_count	12
6.2 Device	14
6.2.1 Функции	14
6.2.1.1 orfa_close	14
6.2.1.2 orfa_open	14
6.3 Reply	15
6.3.1 Функции	15
6.3.1.1 orfa_read_reply	15
6.3.1.2 orfa_str_reply_type	16
6.4 I ² C	17
6.4.1 Функции	17

6.4.1.1	orfa_read	17
6.4.1.2	orfa_write	17
6.5	I ² C Transaction	19
6.5.1	Подробное описание	19
6.5.2	Функции	19
6.5.2.1	orfa_tr_commit	19
6.5.2.2	orfa_tr_start	19
6.6	Special Requests	21
6.6.1	Функции	21
6.6.1.1	orfa_clearbus	21
6.6.1.2	orfa_get_clock	21
6.6.1.3	orfa_get_local	22
6.6.1.4	orfa_get_version	22
6.6.1.5	orfa_set_clock	22
6.6.1.6	orfa_set_local	23
7	Директории	25
7.1	Содержание директории include/	25
7.2	Содержание директории lib/	26
7.3	Содержание директории include/orfa/	27
7.4	Содержание директории prog/	28
8	Структуры данных	29
8.1	Структура orfadev	29
8.1.1	Подробное описание	31
8.2	Структура orfadrivers	32
8.2.1	Подробное описание	33
8.3	Структура orfareply	34
8.3.1	Подробное описание	35
8.3.2	Перечисления	35
8.3.2.1	orfareply_type	35
9	Файлы	37
9.1	Файл include/orfa/intro.h	37
9.1.1	Подробное описание	38
9.2	intro.h	38
9.3	Файл include/orfa/orfa.h	39
9.3.1	Подробное описание	40

9.3.2	Перечисления	40
9.3.2.1	parser_state	40
9.4	orfa.h	41
9.5	Файл lib/intro.c	44
9.5.1	Подробное описание	44
9.6	intro.c	45
9.7	Файл lib/orfa.c	49
9.7.1	Подробное описание	49
9.7.2	Функции	50
9.7.2.1	orfa_close	50
9.7.2.2	orfa_str_reply_type	50
9.8	orfa.c	51
9.9	Файл lib/serial.h	61
9.9.1	Подробное описание	61
9.10	serial.h	62
9.11	Файл lib/serial_posix.c	63
9.11.1	Подробное описание	63
9.12	serial_posix.c	64
9.13	Файл lib/serial_win.c	66
9.13.1	Подробное описание	66
9.14	serial_win.c	67
9.15	Файл prog/lsorfa.c	70
9.15.1	Подробное описание	70
9.16	lsorfa.c	71

Глава 1

Список задач

Файл [orfa.c](#) Test timeouts

Файл [lsorfa.c](#) Add baudrate cli option

Add address cli option

Глава 2

Алфавитный указатель групп

2.1 Группы

Полный список групп.

Introspection	11
Device	14
Reply	15
I ² C	17
I ² C Transaction	19
Special Requests	21

Глава 3

Дерево директорий

3.1 Алфавитный указатель директорий

Дерево директорий

include	25
orfa	27
lib	26
prog	28

Глава 4

Алфавитный указатель структур данных

4.1 Структуры данных

Структуры данных с их кратким описанием.

orfadev (Device structure)	29
orfadivers (Driver list)	32
orfareply (Reply structure)	34

Глава 5

Список файлов

5.1 Файлы

Полный список документированных файлов.

include/orfa/intro.h	38
include/orfa/orfa.h	41
lib/intro.c	45
lib/orfa.c	51
lib/serial.h	62
lib/serial_posix.c	64
lib/serial_win.c	67
prog/lsorfa.c	71

Глава 6

Группы

6.1 Introspection

Структуры данных

- struct `orfadriver`
Driver list.

Функции

- `uint8_t orfa_get_drivers_count (struct orfadev *device, int16_t address)`
- `struct orfadriver * orfa_get_drivers (struct orfadev *device, int16_t address)`
- `bool orfa_free_drivers (struct orfadriver **drivers)`

6.1.1 Функции

6.1.1.1 `bool orfa_free_drivers (struct orfadriver ** drivers)`

Free drivers list

Аргументы:

← *drivers pointer to drivers list head

Возвращает:

true if success, false if fails

См. определение в файле `intro.c` строка

6.1.1.2 `struct orfadriver* orfa_get_drivers (struct orfadev * device, int16_t address) [read]`

Get drivers list Read drivers list from device. Base command: S <adr+w> 00 01 S <adr+r> <6*count> P

Аргументы:

$\leftarrow *device$ pointer to device
 $\leftarrow address$ if < 0 then used local address


Возвращает:

pointer to drivers list head, NULL if fails

См. определение в файле [intro.c](#) строка

Перекрестные ссылки [orfareply::data](#), [orfareply::OR_READ](#), [orfareply::OR_WRITE](#), [orfa_get_drivers_count\(\)](#), [orfa_read\(\)](#), [orfa_read_reply\(\)](#), [orfa_str_reply_type\(\)](#), [orfa_tr_commit\(\)](#), [orfa_tr_start\(\)](#), [orfa_write\(\)](#), [orfareply::size](#), [orfareply::type](#) и [orfadrivers::uid](#).

Граф вызовов:



6.1.1.3 uint8_t orfa_get_drivers_count (struct orfadev * device, int16_t address)

Get drivers count Read drivers count from device. Command: S <adr+w> 00 00 S <adr+r> 01 P

Аргументы:

$\leftarrow *device$ pointer to device
 $\leftarrow address$ if < 0 then used local address

Возвращает:


count if success, 0 if fails

См. определение в файле [intro.c](#) строка

Перекрестные ссылки [orfareply::data](#), [orfareply::OR_READ](#), [orfareply::OR_WRITE](#), [orfa_read\(\)](#), [orfa_read_reply\(\)](#), [orfa_str_reply_type\(\)](#), [orfa_tr_commit\(\)](#), [orfa_tr_start\(\)](#), [orfa_write\(\)](#), [orfareply::size](#) и [orfareply::type](#).

Используется в [orfa_get_drivers\(\)](#).

Граф вызовов:



Граф вызова функции:



6.2 Device

Структуры данных

- struct [orfadev](#)
Device structure.

- struct [orfadev](#) * [orfa_open](#) (char *port, int baudrate)
- int [orfa_close](#) (struct [orfadev](#) **device)

6.2.1 Функции

6.2.1.1 int [orfa_close](#) (struct [orfadev](#) ** device)

Close device and free memory.

Аргументы:

← **device pointer to device pointer

Возвращает:

close() ret

См. определение в файле [orfa.c](#) строка

6.2.1.2 struct [orfadev](#)* [orfa_open](#) (char * port, int baudrate) [read]

Open device

Аргументы:

← *port serial port device path string (/dev/ttyS0)
← baudrate 115200, 9600

Возвращает:

pointer to device structure or NULL if fails

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfadev::baudrate](#), [orfadev::clock](#), [orfadev::fd](#), [orfadev::in_transaction](#), [orfadev::local](#), [PCOMMAND](#), [orfadev::port](#) и [orfadev::vars](#).

6.3 Reply

Структуры данных

- struct `orfareply`

Reply structure.

Макросы

- `#define REPLY_DATA_SIZE 65`

Maximum reply size (ORFA's buffers CBF_SIZE=128, BUF_LEN=65).

- struct `orfareply * orfa_read_reply (struct orfadev *device)`
- const char * `orfa_str_reply_type (struct orfareply *reply)`

6.3.1 Функции

6.3.1.1 struct orfareply* orfa_read_reply (struct orfadev * device) [read]

Get request reply Don't forget free() result

Аргументы:

← *device pointer to device

Возвращает:

reply pointer or NULL if fails

См. определение в файле `orfa.c` строка


Перекрестные ссылки `orfadev::fd`, `orfa_str_reply_type()`, `orfareply::size` и `orfadev::vars`.

Используется в `orfa_clearbus()`, `orfa_get_drivers()`, `orfa_get_drivers_count()`, `orfa_get_version()`, `orfa_set_clock()` и `orfa_set_local()`.

Граф вызовов:



Граф вызова функции:



6.3.1.2 const char* orfa_str_reply_type (struct orfareply * reply)

Stringify `orfareply` type

Аргументы:

$\leftarrow \ast \text{reply}$ Reply

Возвращает:


const string

См. определение в файле `orfaf.c` строка

Перекрестные ссылки `orfareply::OR_CLEAR`, `orfareply::OR_CLOCK`, `orfareply::OR_ERROR`, `orfareply::OR_LOCAL`, `orfareply::OR_READ`, `orfareply::OR_VERSION`, `orfareply::OR_WRITE` и `orfareply::type`.


Используется в `orfareply::OR_CLEAR()`, `orfareply::OR_CLOCK()`, `orfareply::OR_ERROR()`, `orfareply::OR_LOCAL()`, `orfareply::OR_REPLY()`, `orfareply::OR_VERSION()` и `orfareply::OR_WRITE()`.

Граф вызова функции:



6.4 I²C

Граф связей класса I²C:



Группы

- [I²C Transaction](#)

Функции

- `bool orfa_write (struct orfadev *device, int16_t address, uint8_t *data, uint8_t size)`
- `bool orfa_read (struct orfadev *device, int16_t address, uint8_t size)`

6.4.1 Функции

6.4.1.1 `bool orfa_read (struct orfadev * device, int16_t address, uint8_t size)`

Read request

Аргументы:

- ← *device pointer to device
- ← address if < 0 then used local address
- ← read bytes count

Возвращает:


true if success, false if fails

См. определение в файле `orfa.c` строка

Перекрестные ссылки `orfadev::fd`, `orfadev::in_transaction` и `orfadev::local`.

Используется в `orfa_get_drivers()` и `orfa_get_drivers_count()`.

Граф вызова функции:



6.4.1.2 `bool orfa_write (struct orfadev * device, int16_t address, uint8_t * data, uint8_t size)`

Write request

Аргументы:

← *device pointer to device
← address if < 0 then used local address
← *data pointer to data block
← size size of data block

Возвращает:

true if success, false if fails

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfa::fd](#), [orfa::in_transaction](#) и [orfa::local](#).


Используется в [orfa_get_drivers\(\)](#) и [orfa_get_drivers_count\(\)](#).

Граф вызова функции:



6.5 I²C Transaction

Граф связей класса I²C Transaction:



Функции

- void `orfa_tr_start` (struct `orfadev` *device)
- bool `orfa_tr_commit` (struct `orfadev` *device)

6.5.1 Подробное описание

I²C transaction is a command ‘S ... [S ...]] P’

6.5.2 Функции

6.5.2.1 bool `orfa_tr_commit` (struct `orfadev` * device)

Commit transaction

Аргументы:

← *device pointer to device

Возвращает:


true if success, false if fails

См. определение в файле `orfa.c` строка

Перекрестные ссылки `orfadev::fd` и `orfadev::in_transaction`.

Используется в `orfa_get_drivers()` и `orfa_get_drivers_count()`.

Граф вызова функции:



6.5.2.2 void `orfa_tr_start` (struct `orfadev` * device)

Start I²C transaction

Аргументы:


← *device pointer to device

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfa::in_transaction](#).

Используется в [orfa_get_drivers\(\)](#) и [orfa_get_drivers_count\(\)](#).

Граф вызова функции:



6.6 Special Requests

Функции

- `char * orfa_get_version (struct orfadev *device)`
- `int orfa_get_clock (struct orfadev *device)`
- `bool orfa_set_clock (struct orfadev *device, uint16_t clock)`
- `uint8_t orfa_get_local (struct orfadev *device)`
- `bool orfa_set_local (struct orfadev *device, uint8_t local)`
- `bool orfa_clearbus (struct orfadev *device)`

6.6.1 Функции

6.6.1.1 `bool orfa_clearbus (struct orfadev * device)`

Clear I²C bus

Аргументы:

\leftarrow `*device` pointer to device


Возвращает:

true if success, false if fails

См. определение в файле `orfa.c` строка

Перекрестные ссылки `orfadev::fd`, `orfareply::OR_CLEAR`, `orfa_read_reply()`, `orfa_str_reply_type()` и `orfareply::type`.

Граф вызовов:



6.6.1.2 `int orfa_get_clock (struct orfadev * device)`

Get I²C clock

Аргументы:

\leftarrow `*device` pointer to device

Возвращает:

current clock

См. определение в файле `orfa.c` строка

Перекрестные ссылки `orfadev::clock`.

6.6.1.3 uint8_t orfa_get_local (struct orfadev * device)

Get ORFA local I²C address

Аргументы:

← *device pointer to device

Возвращает:

current local address

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfadev::local](#).

6.6.1.4 char* orfa_get_version (struct orfadev * device)

Get protocol version Don't foget free() result.

Аргументы:

← *device pointer to device


Возвращает:

string ptr if success, NULL if fails

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfareply::data](#), [orfadev::fd](#), [orfareply::OR_VERSION](#), [orfa_read_reply\(\)](#), [orfa_str_reply_type\(\)](#), [orfareply::size](#) и [orfareply::type](#).

Граф вызовов:



6.6.1.5 bool orfa_set_clock (struct orfadev * device, uint16_t clock)

Set I²C clock

Аргументы:

← *device pointer to device

← clock new clock in kHz


Возвращает:

true if success, false if fails

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки `orfadev::clock`, `orfareply::data`, `orfadev::fd`, `orfareply::OR_CLOCK`, `orfa_-read_reply()`, `orfa_str_reply_type()`, `orfareply::size` и `orfareply::type`.

Граф вызовов:



6.6.1.6 bool orfa_set_local (struct orfadev * device, uint8_t local)

Set ORFA local I²C address

Аргументы:

\leftarrow *device pointer to device
local new address


Возвращает:

true if success, false if fails

См. определение в файле `orfa.c` строка

Перекрестные ссылки `orfareply::data`, `orfadev::fd`, `orfadev::local`, `orfareply::OR_LOCAL`, `orfa_-read_reply()`, `orfa_str_reply_type()`, `orfareply::size` и `orfareply::type`.

Граф вызовов:



Глава 7

Директории


7.1 Содержание директории `include/`



Директории

- директория `orfa`


7.2 Содержание директории lib/



Файлы

- файл `intro.c`
- файл `orfa.c`
- файл `serial.h`
- файл `serial_posix.c`
- файл `serial_win.c`


7.3 Содержание директории include/orfa/



Файлы

- файл [intro.h](#)
- файл [orfa.h](#)

7.4 Содержание директории prog/



Файлы

- файл `lsorfa.c`

Глава 8


Структуры данных

8.1 Структура orfadem

Device structure.

```
#include <orfa.h>
```

Граф связей класса orfadem:



Поля данных

- **char * port**
Serial device string.
- **int baudrate**
Serial baud rate (115200 etc.).
- **FD_TYPE fd**
Opened file descriptor.
- **uint8_t local**
Local I²C device address.

- `uint16_t clock`
I²C clock speed (kHz).
- `bool in_transaction`
Transaction started.
- `struct parser_vars vars`
Parser internal vars.

8.1.1 Подробное описание

Device structure.

См. определение в файле `orfa.h` строка

Объявления и описания членов структуры находятся в файле:


- `include/orfa/orfa.h`

8.2 Структура orfadrivers

Driver list.

```
#include <intro.h>
```

Граф связей класса orfadrivers:



Поля данных

- **uint16_t uid**
Driver Unique ID (UID).
- **uint8_t major_version**
Major Version.
- **uint8_t minor_version**
Minor Version.
- **uint8_t start_addr**

First register address.

- `uint8_t count`
Registers count.

8.2.1 Подробное описание

Driver list.

См. определение в файле [intro.h](#) строка

Объявления и описания членов структуры находятся в файле:


- `include/orfa/intro.h`

8.3 Структура orfareply

Reply structure.

```
#include <orfa.h>
```

Граф связей класса orfareply:



Открытые типы

- enum `orfareply_type` {
 `OR_WRITE, OR_READ, OR_VERSION, OR_CLOCK,`
`OR_LOCAL, OR_CLEAR, OR_ERROR` }

Reply type.

Поля данных

- enum `orfareply::orfareply_type type`
Reply type.
- `uint8_t size`
Reply size ($0 < \text{size} < \text{REPLY_DATA_SIZE}$).
- `uint8_t data [REPLY_DATA_SIZE]`
Reply data.

8.3.1 Подробное описание

Reply structure.

См. определение в файле [orfa.h](#) строка

8.3.2 Перечисления

8.3.2.1 enum orfareply_type

Reply type.

Элементы перечислений:

- OR_WRITE I²C write reply (SW command).
- OR_READ I²C read reply (SR command).
- OR_VERSION Get Version reply (V command).
- OR_CLOCK Set I²C Clock reply (C command).
- OR_LOCAL Set ORFA's core slave I²C address (L command).
- OR_CLEAR Clear Bus reply (X command).
- OR_ERROR ERROR reply (if error expected).

См. определение в файле [orfa.h](#) строка

Объявления и описания членов структуры находятся в файле:

- [include/orfa/orfa.h](#)


Глава 9

Файлы


9.1 Файл include/orfa/intro.h

```
#include <orfa/orfa.h>
```

Граф включаемых заголовочных файлов для intro.h:



Граф файлов, в которые включается этот файл:



Структуры данных

- struct `orfadriver`
Driver list.

Функции

- uint8_t `orca_get_drivers_count` (struct `orfadev` *device, int16_t address)
- struct `orfadriver` * `orca_get_drivers` (struct `orfadev` *device, int16_t address)
- bool `orca_free_drivers` (struct `orfadriver` **drivers)

9.1.1 Подробное описание

ORFA Introspection driver

Автор:

Vladimir Ermakov

См. определение в файле [intro.h](#)

9.2 intro.h

```


00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00029 #ifndef LIBORFAINTRO_H
00030 #define LIBORFAINTRO_H
00031
00032 #include <orfa/orfa.h>
00033
00039
00040 struct orfadriver {
00041     // private
00042     struct orfadriver *next;
00043     // public
00044     uint16_t uid;
00045     uint8_t major_version;
00046     uint8_t minor_version;
00047     uint8_t start_addr;
00048     uint8_t count;
00049 };
00050
00058 uint8_t orfa_get_drivers_count(struct orfadev *device, int16_t address);
00059
00067 struct orfadriver *orfa_get_drivers(struct orfadev *device, int16_t address);
00068
00073 bool orfa_free_drivers(struct orfadriver **drivers);
00074
00076
00077 #endif // LIBORFAINTRO_H
00078

```


9.3 Файл include/orfa/orfa.h

```
#include <stdint.h>
#include <stdbool.h>
#include <stdlib.h>
```

Граф включаемых заголовочных файлов для orfa.h:



Граф файлов, в которые включается этот файл:



Структуры данных

- struct parser_vars
- struct orfadef

Device structure.

- struct orfareply

Reply structure.

Макросы

- #define REPLY_DATA_SIZE 65

Maximum reply size (ORFA's buffers CBF_SIZE=128, BUF_LEN=65).

Перечисления

- enum parser_state {
 PCOMMAND, PSTART, PSWACK, PBYTE1,
 PBYTE1_OR_STOP, PBYTE2, PVERSION, PERROR,
 PEOL }

Функции

- `bool orfa_write (struct orfadev *device, int16_t address, uint8_t *data, uint8_t size)`
- `bool orfa_read (struct orfadev *device, int16_t address, uint8_t size)`
- `void orfa_tr_start (struct orfadev *device)`
- `bool orfa_tr_commit (struct orfadev *device)`
- `char * orfa_get_version (struct orfadev *device)`
- `int orfa_get_clock (struct orfadev *device)`
- `bool orfa_set_clock (struct orfadev *device, uint16_t clock)`
- `uint8_t orfa_get_local (struct orfadev *device)`
- `bool orfa_set_local (struct orfadev *device, uint8_t local)`
- `bool orfa_clearbus (struct orfadev *device)`

- `struct orfadev * orfa_open (char *port, int baudrate)`
- `int orfa_close (struct orfadev **device)`

- `struct orfareply * orfa_read_reply (struct orfadev *device)`
- `const char * orfa_str_reply_type (struct orfareply *reply)`

9.3.1 Подробное описание

ORFA

Автор:

Vladimir Ermakov

См. определение в файле `orfa.h`

9.3.2 Перечисления

9.3.2.1 enum parser_state

Элементы перечислений:

- `PCOMMAND` Detect command.
- `PSTART` Parse S command reply.
- `PSWACK` SW Ack counter.
- `PBYTE1` First nibble.
- `PBYTE1_OR_STOP` First nibble or stop.
- `PBYTE2` Second nibble.
- `PVERSION` Parse V command reply.
- `PERROR` Parse ERROR reply.
- `PEOL` Wait end of line.

См. определение в файле `orfa.h` строка

9.4 orfa.h

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00029 #ifndef LIBORFA_H
00030 #define LIBORFA_H
00031
00032 #include <stdint.h>
00033 #include <stdbool.h>
00034 #include <stdlib.h>
00035
00036 #ifdef WIN32
00037 # include <windows.h>
00038 typedef HANDLE FD_TYPE;
00039 # define INVALID_FD_VAL INVALID_HANDLE_VALUE
00040 #else
00041 typedef int FD_TYPE;
00042 # define INVALID_FD_VAL -1
00043 #endif
00044
00045 #ifdef __cplusplus
00046 extern "C" {
00047 #endif
00048
00049 // -- Private types --
00050
00051 enum parser_state {
00052     PCOMMAND,
00053     PSTART,
00054     PSWACK,
00055     PBYTE1,
00056     PBYTE1_OR_STOP,
00057     PBYTE2,
00058     PVERSION,
00059     PERROR,
00060     PEOL
00061 };
00062
00063 struct parser_vars {
00064     enum parser_state state;
00065     enum parser_state pb2ret;
00066     int8_t pb2cnt;
00067     uint8_t byte;
00068     bool is_valid;

```

```

00070 };
00071
00072 // -- Public types --
00073
00079
00080 struct orfadev {
00081     // public
00082     char *port;
00083     int baudrate;
00084     // private
00085     FD_TYPE fd;
00086     uint8_t local;
00087     uint16_t clock;
00088     bool in_transaction;
00089     struct parser_vars vars;
00090 };
00091
00093
00099
00100 #define REPLY_DATA_SIZE 65
00101
00103 struct orfareply {
00105     enum orfareply_type {
00106         OR_WRITE,
00107         OR_READ,
00108         OR_VERSION,
00109         OR_CLOCK,
00110         OR_LOCAL,
00111         OR_CLEAR,
00112         OR_ERROR,
00113     } type;
00114     uint8_t size;
00115     uint8_t data[REPLY_DATA_SIZE];
00116 };
00117
00119
00120 // -- Public functions --
00121
00131 struct orfadev *orfa_open(char *port, int baudrate);
00132
00137 int orfa_close(struct orfadev **device);
00138
00140
00153 bool orfa_write(struct orfadev *device, int16_t address, uint8_t *data,
00154     uint8_t size);
00155
00162 bool orfa_read(struct orfadev *device, int16_t address, uint8_t size);
00163
00172 void orfa_tr_start(struct orfadev *device);
00173
00178 bool orfa_tr_commit(struct orfadev *device);
00179
00182
00192 struct orfareply *orfa_read_reply(struct orfadev *device);
00193
00198 const char *orfa_str_reply_type(struct orfareply *reply);
00199
00201
00212 char *orfa_get_version(struct orfadev *device);
00213
00218 int orfa_get_clock(struct orfadev *device);
00219
00225 bool orfa_set_clock(struct orfadev *device, uint16_t clock);
00226
00231 uint8_t orfa_get_local(struct orfadev *device);
00232
00238 bool orfa_set_local(struct orfadev *device, uint8_t local);


```

```
00239
00244 bool orfa_clearbus(struct orfadev *device);
00245
00247
00248 #ifdef __cplusplus
00249 }; // extern "C"
00250 #endif
00251
00252 #endif // LIBORFA_H
00253
```

9.5 Файл lib/intro.c

```
#include <orfa/intro.h>
#include <stdio.h>
```

Граф включаемых заголовочных файлов для intro.c:



Функции

- `uint8_t orfa_get_drivers_count (struct orfadev *device, int16_t address)`
- `struct orfadrv * orfa_get_drivers (struct orfadev *device, int16_t address)`
- `bool orfa_free_drivers (struct orfadrv **drivers)`

9.5.1 Подробное описание

ORFA Introspection driver See details here: http://roboforum.ru/wiki/ORFA_Introspection_driver

Автор:

Vladimir Ermakov

См. определение в файле `intro.c`

9.6 intro.c

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00031 #include <orfa/intro.h>
00032 #include <stdio.h>
00033
00034 // introspection register always zero
00035 #define INTRO 0x00
00036
00037 uint8_t orfa_get_drivers_count(struct orfadev *device, int16_t address)
00038 {
00039     struct orfareply *reply;
00040     uint8_t buf[] = {INTRO, 0};
00041     uint8_t count;
00042
00043     if (device == NULL) {
00044         perror("pointer error!\n");
00045         return 0;
00046     }
00047
00048     // transaction
00049     orfa_tr_start(device);
00050     if (!orfa_write(device, address, buf, 2)) {
00051         perror("get_drivers_count: write return false!\n");
00052         return 0;
00053     }
00054     if (!orfa_read(device, address, 1)) {
00055         perror("get_drivers_count: read return false!\n");
00056         return 0;
00057     }
00058     if (!orfa_tr_commit(device)) {
00059         perror("get_drivers_count: commit return false!\n");
00060         return 0;
00061     }
00062     // end transaction
00063
00064     if ((reply = orfa_read_reply(device)) == NULL) {
00065         perror("get_drivers_count: no reply\n");
00066         return 0;
00067     }
00068     if (reply->type != OR_WRITE) {
00069         fprintf(stderr, "get_drivers_count: incorrect reply type: %s\n",
00070             orfa_str_reply_type(reply));

```

```

00071     free(reply);
00072     return 0;
00073 }
00074 free(reply);
00075
00076 if ((reply = orfa_read_reply(device)) == NULL) {
00077     perror("get_drivers_count: no reply\n");
00078     return 0;
00079 }
00080 if (reply->type != OR_READ) {
00081     fprintf(stderr, "get_drivers_count: incorrect reply type: %s\n",
00082             orfa_str_reply_type(reply));
00083     free(reply);
00084     return 0;
00085 }
00086 if (reply->size != 1) {
00087     fprintf(stderr, "get_drivers_count: wrong reply size: %i\n",
00088             reply->size);
00089     free(reply);
00090     return 0;
00091 }
00092
00093 count = reply->data[0];
00094 free(reply);
00095
00096 return count;
00097 }
00098
00099 /* Calculated for 128 char / 64 byte ORFA's cbf_t
00100 * - size of one pkg: 6 byte (12 chars)
00101 * - reply header and end (SWAASR ... P\n): 8 chars
00102 */
00103 #define MAX_PER_PKG 10
00104 #define PKG_LEN 6
00105
00106 struct orfadriver *orca_get_drivers(struct orfaudev *device, int16_t address)
00107 {
00108     struct orfadriver *head=NULL, *driver;
00109     struct orfareply *reply;
00110     uint8_t count;
00111     uint8_t buf[] = {INTRO, 1};
00112
00113     if ((count=orca_get_drivers_count(device, address)) == 0) {
00114         perror("get_drivers: count == 0\n");
00115         return NULL;
00116     }
00117
00118     uint8_t max_cnt = count / MAX_PER_PKG;
00119     uint8_t min_cnt = count % MAX_PER_PKG;
00120     uint8_t min_num = MAX_PER_PKG * max_cnt + 1;
00121     uint8_t reply_cnt = max_cnt*2 + (min_cnt)? 2:0;
00122
00123     // read maximum long packets
00124     for (int i=0; i<max_cnt; i++) {
00125         buf[1] = MAX_PER_PKG * i + 1;
00126         // transaction
00127         orfa_tr_start(device);
00128         if (!orca_write(device, address, buf, 2)) {
00129             return NULL;
00130         }
00131         if (!orca_read(device, address, MAX_PER_PKG * PKG_LEN)) {
00132             return NULL;
00133         }
00134         if (!orca_tr_commit(device)) {
00135             return NULL;
00136         }
00137     // end transaction

```

```

00138     }
00139
00140     // read last elements
00141     buf[1] = min_num;
00142     // transaction
00143     orfa_tr_start(device);
00144     if (!orca_write(device, address, buf, 2)) {
00145         return NULL;
00146     }
00147     if (!orca_read(device, address, min_cnt * PKG_LEN)) {
00148         return NULL;
00149     }
00150     if (!orca_tr_commit(device)) {
00151         return NULL;
00152     }
00153     // end transaction
00154
00155     for (int i=0; i < reply_cnt; i++) {
00156         if ((reply = orfa_read_reply(device)) == NULL) {
00157             perror("get_drivers: read_reply() return NULL!\n");
00158             return head;
00159         }
00160
00161         if (reply->type == OR_READ) {
00162             if (reply->size % 6) {
00163                 fprintf(stderr, "get_drivers: wrong read reply size: %i\n",
00164                     reply->size);
00165             } else {
00166                 for (int pi=0; pi < reply->size; pi += 6) {
00167                     if ((driver = malloc(sizeof(struct orfadriver))) == NULL) {
00168                         perror("Out of memory!\n");
00169                         return head;
00170                     }
00171
00172                     driver->next = head;
00173                     driver->uid = (reply->data[pi+0] << 8)
00174                         | (reply->data[pi+1]);
00175                     driver->major_version = reply->data[pi+2];
00176                     driver->minor_version = reply->data[pi+3];
00177                     driver->start_addr = reply->data[pi+4];
00178                     driver->count = reply->data[pi+5];
00179                     head = driver;
00180
00181                 }
00182             }
00183         } else if (reply->type != OR_WRITE) {
00184             fprintf(stderr, "get_drivers: wrong reply type: %s\n",
00185                 orfa_str_reply_type(reply));
00186         }
00187
00188         free(reply);
00189     }
00190
00191     return head;
00192 }
00193
00194 bool orfa_free_drivers(struct orfadriver **drivers)
00195 {
00196     struct orfadriver *head;
00197
00198     if (drivers == NULL) {
00199         perror("pointer error!\n");
00200         return false;
00201     }
00202     if (*drivers == NULL) {
00203         perror("pointer error!\n");
00204         return false;


```

```
00205      }
00206
00207      do {
00208          head = (*drivers)->next;
00209          free(*drivers);
00210          *drivers = head;
00211      } while (head != NULL);
00212
00213      *drivers = NULL;
00214
00215      return true;
00216  }
00217
```

9.7 Файл lib/orfa.c

```
#include <orfa/orfa.h>
#include "serial.h"
#include <stdio.h>
#include <errno.h>
#include <string.h>
#include <ctype.h>
```

Граф включаемых заголовочных файлов для orfa.c:



Функции

- `struct orfadev * orfa_open (char *port, int baudrate)`
- `int orfa_close (struct orfadev **device)`
- `void orfa_tr_start (struct orfadev *device)`
- `bool orfa_tr_commit (struct orfadev *device)`
- `bool orfa_write (struct orfadev *device, int16_t address, uint8_t *data, uint8_t size)`
- `bool orfa_read (struct orfadev *device, int16_t address, uint8_t size)`
- `struct orfareply * orfa_read_reply (struct orfadev *device)`
- `const char * orfa_str_reply_type (struct orfareply *reply)`
- `char * orfa_get_version (struct orfadev *device)`
- `int orfa_get_clock (struct orfadev *device)`
- `bool orfa_set_clock (struct orfadev *device, uint16_t clock)`
- `uint8_t orfa_get_local (struct orfadev *device)`
- `bool orfa_set_local (struct orfadev *device, uint8_t local)`
- `bool orfa_clearbus (struct orfadev *device)`

9.7.1 Подробное описание

ORFA

Автор:

Vladimir Ermakov

[Необходимо сделать](#)

Test timeouts

См. определение в файле `orfa.c`

9.7.2 Функции

9.7.2.1 int orfa_close (struct orfadev ** device)

Close device and free memory.

Аргументы:

← **device pointer to device pointer

Возвращает:

close() ret

См. определение в файле [orfa.c](#) строка

9.7.2.2 const char* orfa_str_reply_type (struct orfareply * reply)

Stringify [orfareply](#) type

Аргументы:

← *reply Reply

Возвращает:


const string

См. определение в файле [orfa.c](#) строка

Перекрестные ссылки [orfareply::OR_CLEAR](#), [orfareply::OR_CLOCK](#), [orfareply::OR_ERROR](#), [orfareply::OR_LOCAL](#), [orfareply::OR_READ](#), [orfareply::OR_VERSION](#), [orfareply::OR_WRITE](#) и [orfareply::type](#).

Используется в [orfa_clearbus\(\)](#), [orfa_get_drivers\(\)](#), [orfa_get_drivers_count\(\)](#), [orfa_get_version\(\)](#), [orfa_read_reply\(\)](#), [orfa_set_clock\(\)](#) и [orfa_set_local\(\)](#).

Граф вызова функции:



9.8 orfa.c

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00031 #include <orfa/orfa.h>
00032 #include "serial.h"
00033
00034 #include <stdio.h>
00035 #include <errno.h>
00036 #include <string.h>
00037 #include <ctype.h>
00038
00039 #define CHECK_POINTER_R(p, r) \
00040     if (p == NULL) { \
00041         perror("pointer error!\n"); \
00042         return r; \
00043     }
00044
00045 #define CHECK_POINTER_RF(p) CHECK_POINTER_R(p, false)
00046 #define CHECK_POINTER_RN(p) CHECK_POINTER_R(p, NULL)
00047
00048 #define CHECK_ALLOC_R(p, r) \
00049     if (p == NULL) { \
00050         perror("Out of memory!\n"); \
00051         return r; \
00052     }
00053
00054 #define CHECK_ALLOC_RN(p) CHECK_ALLOC_R(p, NULL)
00055
00056 // == Private ==
00057 // -- private char convert functions --
00058
00063 static int8_t xtoi(uint8_t c)
00064 {
00065     if((c >= '0') && (c <= '9')) {
00066         return c - '0';
00067     } else if((c >= 'A')&&(c <= 'F')) {
00068         return c - 'A' + 10;
00069     } else {
00070         return -1;
00071     }
00072 }
```

```

00073
00078 static char itox(uint8_t c)
00079 {
00080     char ret;
00081
00082     if (c <= 0x09) {
00083         ret = '0' + c;
00084     } else if (c <= 0x0f) {
00085         ret = 'A' + c - 10;
00086     } else {
00087         ret = 'X';
00088     }
00089     return ret;
00090 }
00091
00092 // -- parser --
00093
00094 #define REPLY_DATA_ADD(_reply, _data) \
00095     (_reply)->data[(_reply)->size] = (_data); \
00096     if ((_reply)->size < REPLY_DATA_SIZE-1) { \
00097         (_reply)->size += 1; \
00098     }
00099
00106 static bool
00107 parse(struct parser_vars *self, uint8_t c, struct orfareply *reply)
00108 {
00109     int8_t tmp;
00110
00111     if (self == NULL || reply == NULL) {
00112         perror("pointer error!\n");
00113         return false;
00114     }
00115
00116     // clean input
00117     c = toupper(c);
00118     c = (c == '\r')? '\n' : c;
00119
00120     switch (self->state) {
00121         case PCOMMAND:
00122             self->pb2cnt = 1;
00123             self->is_valid = true;
00124             reply->size = 0;
00125
00126             switch (c) {
00127                 case 'S':
00128                     self->state = PSTART;
00129                     self->pb2cnt = -1;
00130                     break;
00131
00132                 case 'C':
00133                     self->state = PBYTE1;
00134                     self->pb2cnt = 2;
00135                     reply->type = OR_CLOCK;
00136                     break;
00137
00138                 case 'L':
00139                     self->state = PBYTE1;
00140                     reply->type = OR_LOCAL;
00141                     break;
00142
00143                 case 'X':
00144                     self->state = PEOL;
00145                     reply->type = OR_CLEAR;
00146                     reply->size = 1;
00147                     reply->data[0] = true;
00148                     break;
00149

```

```

00150     case 'V':
00151         self->state = PVERSION;
00152         reply->type = OR_VERSION;
00153         break;
00154
00155     case 'E':
00156         self->state = PEROR;
00157         reply->type = OR_ERROR;
00158         break;
00159
00160     case '\n':
00161         // skip blank line
00162         break;
00163
00164     default:
00165         // unknown command
00166         self->state = PEOL;
00167         self->is_valid = false;
00168         break;
00169     }
00170     break;
00171
00172 case PSTART:
00173     switch (c) {
00174         case 'R':
00175             self->state = PBYTE1_OR_STOP;
00176             reply->type = OR_READ;
00177             reply->size = 0;
00178             break;
00179
00180         case 'W':
00181             self->state = PSWACK;
00182             reply->type = OR_WRITE;
00183             reply->size = 0;
00184             break;
00185
00186         case '\n':
00187             // P expected
00188             self->is_valid = false;
00189             self->state = PCOMMAND;
00190             break;
00191
00192         default:
00193             self->is_valid = false;
00194             self->state = PEOL;
00195             break;
00196     }
00197     break;
00198
00199 case PSWACK:
00200     switch (c) {
00201         case 'A':
00202             REPLY_DATA_ADD(reply, true);
00203             break;
00204
00205         case 'P':
00206             self->state = PEOL;
00207             break;
00208
00209         case 'S':
00210             self->state = PSTART;
00211             return true;
00212             break;
00213
00214         case '\n':
00215             // P expected
00216             self->is_valid = false;

```

```

00217         self->state = PCOMMAND;
00218         break;
00219
00220     default:
00221         self->is_valid = false;
00222         self->state = PEOL;
00223         break;
00224     }
00225     break;
00226
00227 case PBYTE1:
00228 case PBYTE1_OR_STOP:
00229     self->pb2ret = self->state;
00230     tmp = xtoi(c);
00231     if (tmp != -1) {
00232         self->byte = tmp << 4;
00233         self->state = PBYTE2;
00234     } else if (self->state == PBYTE1_OR_STOP && c == 'S') {
00235         // Next S reply start (transaction)
00236         self->state = PSTART;
00237         return true;
00238     } else if (self->state == PBYTE1_OR_STOP && c == 'P') {
00239         // S reply end
00240         self->state = PEOL;
00241     } else if (c == '\n') {
00242         // P expected
00243         self->is_valid = false;
00244         self->state = PCOMMAND;
00245     } else {
00246         // error
00247         self->state = PEOL;
00248         self->is_valid = false;
00249     }
00250     break;
00251
00252 case PBYTE2:
00253     tmp = xtoi(c);
00254     if (tmp != -1) {
00255         self->byte |= tmp;
00256         REPLY_DATA_ADD(reply, self->byte);
00257
00258         // all bytes readed?
00259         self->pb2cnt -= (self->pb2cnt > 0)? 0 : 1;
00260         self->state = (self->pb2cnt == 0)? PEOL : self->pb2ret;
00261     } else if (c == '\n') {
00262         // P expected
00263         self->is_valid = false;
00264         self->state = PCOMMAND;
00265     } else {
00266         self->is_valid = false;
00267         self->state = PEOL;
00268     }
00269     break;
00270
00271 case PVERSION:
00272     if (c == '\n') {
00273         self->state = PCOMMAND;
00274         // gurantee that version string end at \0
00275         reply->data[REPLY_DATA_SIZE-1] = '\0';
00276         return true;
00277     }
00278     REPLY_DATA_ADD(reply, c);
00279     break;
00280
00281 case PERROR:
00282     switch (c) {
00283         case 'R':

```

```

00284     case 'O':
00285         // eRROR
00286         break;
00287
00288     case ' ':
00289         // error code start
00290         self->state = PBYTE1;
00291         break;
00292
00293     case '\n':
00294         // P expected
00295         self->is_valid = false;
00296         self->state = PCOMMAND;
00297         break;
00298
00299     default:
00300         self->is_valid = false;
00301         self->state = PEOL;
00302         break;
00303     }
00304     break;
00305
00306     case PEOL:
00307         if (c == '\n') {
00308             self->state = PCOMMAND;
00309
00310             if (self->is_valid) {
00311                 return true;
00312             }
00313         }
00314         break;
00315     }
00316
00317     return false;
00318 }
00319
00320 // === Public ===
00321
00322 // Open device
00323 struct orfadev *orca_open(char *port, int baudrate)
00324 {
00325     FD_TYPE fd = open_and_configure(port, baudrate);
00326     if (fd == INVALID_FD_VAL) {
00327         return NULL;
00328     }
00329
00330     struct orfadev *device = malloc(sizeof(struct orfadev));
00331     CHECK_ALLOC_RN(device);
00332
00333     // set data
00334     device->fd = fd;
00335     device->port = port;
00336     device->baudrate = baudrate;
00337     device->clock = 100; // power-on default 100 kHz
00338     device->local = 0xAA; // power-on default
00339     device->in_transaction = false;
00340     device->vars.state = PCOMMAND;
00341
00342     return device;
00343 }
00344
00345 // Close device
00346 int orca_close(struct orfadev **device)
00347 {
00348     CHECK_POINTER_R(device, -1);
00349     CHECK_POINTER_R(*device, -1);
00350

```

```

00351     int ret = posix_close((*device)->fd);
00352     free(*device);
00353     *device = NULL;
00354
00355     return ret;
00356 }
00357
00358 // I2C transaction start
00359 void orfa_tr_start(struct orfadev *device)
00360 {
00361     CHECK_POINTER_R(device, );
00362
00363     device->in_transaction = true;
00364 }
00365
00366 // I2C transaction end
00367 bool orfa_tr_commit(struct orfadev *device)
00368 {
00369     CHECK_POINTER_RF(device);
00370
00371     if (posix_write(device->fd, "P\n", 2) < 2) {
00372         perror("posix_write() failed!\n");
00373         return false;
00374     }
00375
00376     device->in_transaction = false;
00377
00378     return true;
00379 }
00380
00381 // I2C write request
00382 bool orfa_write(struct orfadev *device, int16_t address,
00383                  uint8_t *data, uint8_t size)
00384 {
00385     uint8_t bs[3], address8;
00386
00387     CHECK_POINTER_RF(device);
00388
00389     if (address < 0) {
00390         address8 = device->local;
00391     } else {
00392         address8 = ((uint8_t) address);
00393     }
00394     address8 &= 0xfe;
00395
00396     bs[0] = 'S';
00397     bs[1] = itox(address8 >> 4);
00398     bs[2] = itox(address8 & 0xf);
00399     if (posix_write(device->fd, bs, 3) < 3) {
00400         perror("posix_write() failed!\n");
00401         return false;
00402     }
00403
00404     for (uint8_t i=0; i<size; i++) {
00405         uint8_t b = data[i];
00406         bs[0] = itox(b >> 4);
00407         bs[1] = itox(b & 0xf);
00408         if (posix_write(device->fd, bs, 2) < 2) {
00409             perror("posix_write() failed!\n");
00410             return false;
00411         }
00412     }
00413
00414     if (!device->in_transaction) {
00415         if (posix_write(device->fd, "P\n", 2) < 2) {
00416             perror("posix_write() failed!\n");
00417             return false;

```

```

00418     }
00419 }
00420
00421     return true;
00422 }
00423
00424 // I2C read request
00425 bool orfa_read(struct orfadev *device, int16_t address, uint8_t size)
00426 {
00427     uint8_t bs[5], address8;
00428
00429     CHECK_POINTER_RF(device);
00430
00431     if (address < 0) {
00432         address8 = device->local;
00433     } else {
00434         address8 = ((uint8_t) address);
00435     }
00436     address8 |= 0x01;
00437
00438     bs[0] = 'S';
00439     bs[1] = itox(address8 >> 4);
00440     bs[2] = itox(address8 & 0xf);
00441     bs[3] = itox(size >> 4);
00442     bs[4] = itox(size & 0xf);
00443
00444     if (posix_write(device->fd, bs, 5) < 5) {
00445         perror("posix_write() failed!\n");
00446         return false;
00447     }
00448
00449     if (!device->in_transaction) {
00450         if (posix_write(device->fd, "P\n", 2) < 2) {
00451             perror("posix_write() failed!\n");
00452             return false;
00453         }
00454     }
00455
00456     return true;
00457 }
00458
00459 // get request reply
00460 struct orfareply *orfa_read_reply(struct orfadev *device)
00461 {
00462     CHECK_POINTER_RN(device);
00463
00464     struct orfareply *reply=malloc(sizeof(struct orfareply));
00465     CHECK_ALLOC_RN(reply);
00466
00467     uint8_t buf;
00468     do {
00469         // TODO test timeout
00470         int iret = posix_read(device->fd, &buf, 1);
00471         if (iret < 1) {
00472             fprintf(stderr, "read_reply: posix_read() returns error: %s\n",
00473                     strerror(errno));
00474             free(reply);
00475             return NULL;
00476         }
00477     } while (!parse(&(device->vars), buf, reply) && device->vars.is_valid);
00478
00479     if (!device->vars.is_valid) {
00480         fprintf(stderr, "reply not valid! [type=%s, size=%i]\n",
00481                 orfa_str_reply_type(reply), reply->size);
00482         free(reply);
00483         return NULL;
00484     }

```

```

00485
00486     return reply;
00487 }
00488
00489 const char *orfa_str_reply_type(struct orfareply *reply)
00490 {
00491     CHECK_POINTER_R(reply, "PTRERR");
00492
00493     switch (reply->type) {
00494         case OR_WRITE:  return "OR_WRITE";
00495         case OR_READ:   return "OR_READ";
00496         case OR_VERSION: return "OR_VERSION";
00497         case OR_CLOCK:  return "OR_CLOCK";
00498         case OR_LOCAL:  return "OR_LOCAL";
00499         case OR_CLEAR:  return "OR_CLEAR";
00500         case OR_ERROR:  return "OR_ERROR";
00501         default:        return "TYPEERR";
00502     }
00503 }
00504
00505 // -- ORFA special requests --
00506
00507 // get protocol version string
00508 char *orfa_get_version(struct orfadev *device)
00509 {
00510     CHECK_POINTER_RN(device);
00511
00512     if (posix_write(device->fd, "V\n", 2) < 2) {
00513         perror("version: posix_write() failed!\n");
00514         return NULL;
00515     }
00516
00517     struct orfareply *reply=orfa_read_reply(device);
00518     if (reply == NULL) {
00519         perror("version: no reply\n");
00520         return NULL;
00521     }
00522
00523     if (reply->type != OR_VERSION) {
00524         fprintf(stderr, "version: wrong reply type: %s\n",
00525                 orfa_str_reply_type(reply));
00526         free(reply);
00527         return NULL;
00528     }
00529
00530     if (reply->size == 0) {
00531         perror("version: wrong reply size == 0\n");
00532         return NULL;
00533     }
00534
00535     char *version_str=malloc(reply->size+1);
00536     CHECK_ALLOC_RN(version_str);
00537
00538     // copy version string
00539     memcpy(version_str, &(reply->data), reply->size);
00540     version_str[reply->size+1] = '\0';
00541
00542     free(reply);
00543
00544     return version_str;
00545 }
00546
00547 // get i2c clock
00548 int orfa_get_clock(struct orfadev *device)
00549 {
00550     CHECK_POINTER_R(device, 0);
00551

```

```

00552     return device->clock;
00553 }
00554
00555 // set i2c clock
00556 bool orfa_set_clock(struct orfadev *device, uint16_t clock)
00557 {
00558     uint8_t bs[6];
00559
00560     CHECK_POINTER_RF(device);
00561
00562     bs[0] = 'C';
00563     bs[1] = itox(clock >> 12);
00564     bs[2] = itox((clock >> 8) & 0xf);
00565     bs[3] = itox((clock >> 4) & 0xf);
00566     bs[4] = itox(clock & 0xf);
00567     bs[5] = '\n';
00568     if (posix_write(device->fd, bs, 6) < 6) {
00569         perror("clock: posix_write() failed!\n");
00570         return false;
00571     }
00572
00573 //device->clock = clock;
00574 struct orfareply *reply=orfareply_reply(device);
00575 if (reply == NULL) {
00576     perror("clock: no reply\n");
00577     return false;
00578 }
00579
00580 if (reply->type != OR_CLOCK) {
00581     fprintf(stderr, "clock: wrong reply type: %s\n",
00582             orfareply_type(reply));
00583     free(reply);
00584     return false;
00585 }
00586
00587 if (reply->size != 2) {
00588     fprintf(stderr, "clock: wrong size: %i\n", reply->size);
00589     free(reply);
00590     return false;
00591 }
00592
00593 device->clock = (reply->data[0]<<8)|(reply->data[1]);
00594 free(reply);
00595
00596 return true;
00597 }
00598
00599 // get local device address
00600 uint8_t orfa_get_local(struct orfadev *device)
00601 {
00602     CHECK_POINTER_R(device, 0);
00603
00604     return device->local;
00605 }
00606
00607 // set local device address
00608 bool orfa_set_local(struct orfadev *device, uint8_t local)
00609 {
00610     uint8_t bs[4];
00611
00612     CHECK_POINTER_RF(device);
00613
00614     bs[0] = 'L';
00615     bs[1] = itox(local >> 4);
00616     bs[2] = itox(local & 0xf);
00617     bs[3] = '\n';
00618     if (posix_write(device->fd, bs, 4) < 4) {

```

```


00619     perror("local: posix_write() failed!\n");
00620     return false;
00621 }
00622
00623 //device->local = local;
00624 struct orfareply *reply=orfa_read_reply(device);
00625 if (reply == NULL) {
00626     perror("local: no reply\n");
00627     return false;
00628 }
00629
00630 if (reply->type != OR_LOCAL) {
00631     fprintf(stderr, "local: wrong reply type: %s\n",
00632             orfa_str_reply_type(reply));
00633     free(reply);
00634     return false;
00635 }
00636
00637 if (reply->size != 1) {
00638     fprintf(stderr, "local: wrong size: %i\n", reply->size);
00639     free(reply);
00640     return false;
00641 }
00642
00643 device->local = reply->data[0];
00644 free(reply);
00645
00646 return true;
00647 }
00648
00649 // clear i2c bus
00650 bool orfa_clearbus(struct orfadev *device)
00651 {
00652     CHECK_POINTER_RF(device);
00653
00654     if (posix_write(device->fd, "X\n", 2) < 2) {
00655         perror("clearbus: posix_write() failed!\n");
00656         return false;
00657     }
00658
00659     struct orfareply *reply=orfa_read_reply(device);
00660     if (reply == NULL) {
00661         perror("clearbus: no reply\n");
00662         return false;
00663     }
00664
00665     if (reply->type != OR_CLEAR) {
00666         fprintf(stderr, "clearbus: wrong reply type: %s\n",
00667                 orfa_str_reply_type(reply));
00668         free(reply);
00669         return false;
00670     }
00671
00672     free(reply);
00673
00674     return true;
00675 }
00676

```


9.9 Файл lib/serial.h

```
#include <stdint.h>
#include <stdbool.h>
#include <stdio.h>
#include <unistd.h>
#include <fcntl.h>
#include <termios.h>
```

Граф включаемых заголовочных файлов для serial.h:



Граф файлов, в которые включается этот файл:



9.9.1 Подробное описание

Serial lib

Автор:

Vladimir Ermakov

См. определение в файле [serial.h](#)

9.10 serial.h

```


00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXCEPTED ON
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00029 #ifndef SERIAL_H
00030 #define SERIAL_H
00031
00032 #include <stdint.h>
00033 #include <stdbool.h>
00034 #include <stdio.h>
00035
00036 #ifndef WIN32
00037 // == POSIX ==
00038 # include <unistd.h>
00039 # include <fcntl.h>
00040 # include <termios.h>
00041
00042 # define posix_close(fd) close(fd)
00043 # define posix_write(fd, buf, size) write(fd, buf, size)
00044 # define posix_read(fd, buf, size) read(fd, buf, size)
00045
00046 int open_and_configure(char *port, int baudrate);
00047
00048 #else
00049 // == WIN32 ==
00050 # include <windows.h>
00051
00052 # define posix_close(handle) CloseHandle(handle)
00053
00054 HANDLE open_and_configure(char *port, int baudrate);
00055 int posix_write(HANDLE handle, char *buf, size_t size);
00056 int posix_read(HANDLE handle, char *buf, size_t count);
00057
00058 #endif // !WIN32
00059
00060 #endif // SERIAL_H
00061

```

9.11 Файл lib/serial_posix.c

```
#include "serial.h"
```

Граф включаемых заголовочных файлов для serial_posix.c:



9.11.1 Подробное описание

Serial lib POSIX

Автор:

Vladimir Ermakov

См. определение в файле [serial_posix.c](#)

9.12 serial_posix.c

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00029 #include "serial.h"
00030
00031 static inline void setspeed(struct termios *options, int baudrate)
00032 {
00033     switch (baudrate) {
00034         case 9600: baudrate = B9600; break;
00035         case 115200: baudrate = B115200; break;
00036         default:
00037             fprintf(stderr, "Unsupported baudrate %i, set to 9600\n",
00038                     baudrate);
00039             baudrate = B9600;
00040             break;
00041     }
00042
00043     cfsetispeed(options, baudrate);
00044     cfsetospeed(options, baudrate);
00045 }
00046
00047 int open_and_configure(char *port, int baudrate)
00048 {
00049     struct termios options;
00050
00051     int fd = open(port, O_RDWR|O_NOCTTY|O_NDELAY);
00052     if (fd == -1) {
00053         fprintf(stderr, "open_and_configure: Unable to open %s\n", port);
00054         return -1;
00055     }
00056
00057     // Set blocking
00058     fcntl(fd, F_SETFL, 0);
00059
00060     // Get the current options for the port...
00061     tcgetattr(fd, &options);
00062
00063     // Set the baud rate
00064     setspeed(&options, baudrate);
00065
00066     // Enable the receiver and set local mode, set 8N1


```

```
00067     options.c_cflag |= CLOCAL | CREAD;
00068     options.c_cflag &= ~PARENB;
00069     options.c_cflag &= ~CSTOPB;
00070     options.c_cflag &= ~CSIZE;
00071     options.c_cflag |= CS8;
00072 # ifdef CNEW_RTSCTS
00073     options.c_cflag &= ~CNEW_RTSCTS;
00074 # elif defined(CRTSCTS)
00075     options.c_cflag &= ~CRTSCTS;
00076 # endif
00077 // Raw IO
00078     options.c_lflag &= ~(ICANON | ECHO | ECHOE | ISIG);
00079     options.c_oflag &= ~OPOST;
00080
00081 // 5 sec timeout
00082     options.c_cc[VMIN] = 0;
00083     options.c_cc[VTIME] = 50;
00084
00085 // Set the new options for the port...
00086     tcsetattr(fd, TCSANOW, &options);
00087
00088     return fd;
00089 }
00090
```

9.13 Файл lib/serial_win.c

```
#include "serial.h"
```

Граф включаемых заголовочных файлов для serial_win.c:



9.13.1 Подробное описание

Serial lib WIN32

Автор:

Vladimir Ermakov

См. определение в файле [serial_win.c](#)

9.14 serial_win.c

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXCEPTED AS
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00029 #include "serial.h"
00030
00031 #define W32SERBUFSIZE 4096
00032
00033 // thanks avrdude
00034 #define FORMATMESSAGE(lpMsgBuf) \
00035     LPVOID lpMsgBuf; \
00036     FormatMessage( \
00037         FORMAT_MESSAGE_ALLOCATE_BUFFER | \
00038         FORMAT_MESSAGE_FROM_SYSTEM | \
00039         FORMAT_MESSAGE_IGNORE_INSERTS, \
00040         NULL, \
00041         GetLastError(), \
00042         /* default language */ \
00043         MAKELANGID(LANG_NEUTRAL, SUBLANG_DEFAULT), \
00044         (LPTSTR) &lpMsgBuf, \
00045         0, NULL);
00046
00047
00048 HANDLE open_and_configure(char *port, int baudrate)
00049 {
00050     COMMCONFIG comm_config;
00051     COMMTIMEOUTS comm_timeouts;
00052     DWORD comm_cfg_size = sizeof(COMMCONFIG);
00053     comm_config.dwSize = comm_cfg_size;
00054
00055     HANDLE fd = CreateFileA(port, GENERIC_READ | GENERIC_WRITE, 0, NULL,
00056                             OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
00057     if (fd == INVALID_HANDLE_VALUE) {
00058         FORMATMESSAGE(lpMsgBuf);
00059         fprintf(stderr, "open_and_configure: can't open device \\\"%s\\\": %s\n",
00060                 port, (char*)lpMsgBuf);
00061         LocalFree(lpMsgBuf);
00062
00063         return INVALID_HANDLE_VALUE;
00064     }
00065
00066     if (!SetupComm(fd, W32SERBUFSIZE, W32SERBUFSIZE)) {

```

```

00067     CloseHandle(fd);
00068     fprintf(stderr, "open_and_configure: can't set buffers for \'%s\'\n",
00069             port);
00070
00071     return INVALID_HANDLE_VALUE;
00072 }
00073
00074 // configure port settings
00075 GetCommConfig(fd, &comm_config, &comm_cfg_size);
00076 GetCommState(fd, &(comm_config.dcb));
00077
00078 // set baudrate
00079 switch (baudrate) {
00080     case 9600: comm_config.dcb.BaudRate = CBR_9600; break;
00081     case 115200: comm_config.dcb.BaudRate = CBR_115200; break;
00082     default:
00083         fprintf(stderr, "Unsupported baudrate %i, set to 9600\n",
00084                 baudrate);
00085         comm_config.dcb.BaudRate = CBR_9600;
00086         break;
00087 }
00088
00089 // flow control off
00090 comm_config.dcb.fOutxCtsFlow = FALSE;
00091 comm_config.dcb.fDtrControl = DTR_CONTROL_DISABLE;
00092 comm_config.dcb.fRtsControl = RTS_CONTROL_DISABLE;
00093 comm_config.dcb.fLnX = FALSE;
00094 comm_config.dcb.fOutX = FALSE;
00095
00096 // Binary, 8N1
00097 comm_config.dcb.fBinary = TRUE;
00098 comm_config.dcb.fAbortOnError = FALSE;
00099 comm_config.dcb.fNull = FALSE;
00100 comm_config.dcb.ByteSize = 8;
00101 comm_config.dcb.fParity = NOPARITY;
00102 comm_config.dcb.StopBits = ONESTOPBIT;
00103
00104 // Set the new options...
00105 SetCommConfig(fd, &comm_config, sizeof(COMMCONFIG));
00106
00107 // timeout 5 sec
00108 comm_timeouts.ReadIntervalTimeout = 5000;
00109 comm_timeouts.ReadTotalTimeoutMultiplier = 5000;
00110 comm_timeouts.ReadTotalTimeoutConstant = 0;
00111 comm_timeouts.WriteTotalTimeoutMultiplier = 5000;
00112 comm_timeouts.WriteTotalTimeoutConstant = 0;
00113
00114 SetCommTimeouts(fd, &comm_timeouts);
00115
00116 return fd;
00117 }
00118
00119 int posix_write(HANDLE handle, char *buf, size_t size)
00120 {
00121     int ret;
00122     DWORD written;
00123     if (!WriteFile(handle, buf, size, &written, NULL)) {
00124         FORMATMESSAGE(lpMsgBuf);
00125         fprintf(stderr, "posix_write: write error: %s\n", (char*)lpMsgBuf);
00126         LocalFree(lpMsgBuf);
00127
00128         ret = -1;
00129     } else {
00130         ret = written;
00131     }
00132
00133     return ret;


```

```
00134 }
00135
00136 int posix_read(HANDLE handle, char *buf, size_t count)
00137 {
00138     int ret;
00139     DWORD read;
00140     if (!ReadFile(handle, buf, count, &read, NULL)) {
00141         FORMATMESSAGE(lpMsgBuf);
00142         fprintf(stderr, "posix_read: read error: %s\n", (char*)lpMsgBuf);
00143         LocalFree(lpMsgBuf);
00144         ret = -1;
00145     } else {
00146         ret = read;
00147     }
00148 }
00149
00150     return ret;
00151 }
00152
```

9.15 Файл prog/lsorfa.c

```
#include <stdio.h>
#include <orfa/orfa.h>
#include <orfa/intro.h>
```

Граф включаемых заголовочных файлов для lsorfa.c:



9.15.1 Подробное описание

lsorfa Print ORFA drivers table. And it is a simple example how to use liborfa.so

Автор:

Vladimir Ermakov

[Необходимо сделать](#)

- Add baudrate cli option
- Add address cli option

[См. определение в файле lsorfa.c](#)

9.16 lsorfa.c

```

00001 /*
00002 * libORFA -- PC-side gate library for Open Robotics Firmware Architecture
00003 *
00004 * Copyright (c) 2009 Vladimir Ermakov
00005 *
00006 * Permission is hereby granted, free of charge, to any person obtaining a copy
00007 * of this software and associated documentation files (the "Software"), to deal
00008 * in the Software without restriction, including without limitation the rights
00009 * to use, copy, modify, merge, publish, distribute, sublicense, and/or sell
00010 * copies of the Software, and to permit persons to whom the Software is
00011 * furnished to do so, subject to the following conditions:
00012 *
00013 * The above copyright notice and this permission notice shall be included in
00014 * all copies or substantial portions of the Software.
00015 *
00016 * THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR
00017 * IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY,
00018 * FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE
00019 * AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER
00020 * LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM,
00021 * OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN
00022 * THE SOFTWARE.
00023 *****/
00035 #include <stdio.h>
00036 #include <orfa/orfa.h>
00037 #include <orfa/intro.h>
00038
00039 void print_intro_table(struct orfadrvivers *head)
00040 {
00041     // XXX: check drivers before call this function
00042     struct orfadrvivers *drivers=head;
00043
00044     printf("  UID Version Start Count\n");
00045     printf("----- ----- ----- -----\\n");
00046
00047     do {
00048         printf("0x%04X %5i.%1i 0x%02X %5i\\n", drivers->uid,
00049               drivers->major_version, drivers->minor_version,
00050               drivers->start_addr, drivers->count);
00051     drivers = drivers->next;
00052 } while (drivers != NULL);
00053 }
00054
00055 int main(int argc, char *argv[])
00056 {
00057     int ret=0, close_ret;
00058     char *version_str;
00059     struct orfadev *device;
00060     struct orfadrvivers *drivers=NULL;
00061
00062     if (argc != 2) {
00063         fprintf(stderr, "Usage: %s /dev/ttyS0\\n", argv[0]);
00064         return 1;
00065     }
00066
00067     // TODO: baudrate option
00068     device = orfa_open(argv[1], 115200);
00069     if (device == NULL) {
00070         fprintf(stderr, "Can't open the port: %s\\n", argv[1]);
00071         return 1;
00072     }
00073
00074     // try:

```

```

00075     version_str = orfa_get_version(device);
00076     if (version_str == NULL) {
00077         perror("orfa_get_version: return NULL\n");
00078         ret = 2;
00079         goto close_and_exit;
00080     }
00081
00082     // 0 — best choice for local address
00083     if (!orca_set_local(device, 0)) {
00084         perror("orca_set_local() fails!\n");
00085         ret = 3;
00086         goto close_and_exit;
00087     }
00088
00089     // TODO: address option
00090     drivers = orfa_get_drivers(device, -1);
00091     if (drivers == NULL) {
00092         perror("orca_get_drivers() returned NULL\n");
00093         ret = 4;
00094         goto close_and_exit;
00095     }
00096
00097     printf("Protocol: V%s\n\n", version_str);
00098     print_intro_table(drivers);
00099     orfa_free_drivers(&drivers);
00100     free(version_str);
00101
00102     // finally:
00103     close_and_exit:
00104     if ((close_ret = orfa_close(&device))) {
00105         fprintf(stderr, "orca_close() returned: %i\n", close_ret);
00106         ret = 5;
00107     }
00108
00109     return ret;
00110 }
00111

```

Предметный указатель

Содержание директории include/, 25
Содержание директории include/orfa/, 27
Содержание директории lib/, 26
Содержание директории prog/, 28

Device, 14
 orfa_close, 14
 orfa_open, 14

I²C, 17
 orfa_read, 17
 orfa_write, 17

I²C Transaction, 19

include/orfa/intro.h, 37, 38
include/orfa/orfa.h, 39, 41

Introspection, 11
 orfa_free_drivers, 11
 orfa_get_drivers, 11
 orfa_get_drivers_count, 12

lib/intro.c, 44, 45
lib/orfa.c, 49, 51
lib/serial.h, 61, 62
lib/serial_posix.c, 63, 64
lib/serial_win.c, 66, 67

OR_CLEAR
 orfareply, 35

OR_CLOCK
 orfareply, 35

OR_ERROR
 orfareply, 35

OR_LOCAL
 orfareply, 35

OR_READ
 orfareply, 35

OR_VERSION
 orfareply, 35

OR_WRITE
 orfareply, 35

orfa.c
 orfa_close, 50
 orfa_str_reply_type, 50

orfa.h
 parser_state, 40

PBYTE1, 40
PBYTE1_OR_STOP, 40
PBYTE2, 40
PCOMMAND, 40
PEOL, 40
PERROR, 40
PSTART, 40
PSWACK, 40
PVERSION, 40

orfa_clearbus
 SpReq, 21

orfa_close
 Device, 14
 orfa.c, 50

orfa_free_drivers
 Introspection, 11

orfa_get_clock
 SpReq, 21

orfa_get_drivers
 Introspection, 11

orfa_get_drivers_count
 Introspection, 12

orfa_get_local
 SpReq, 21

orfa_get_version
 SpReq, 22

orfa_open
 Device, 14

orfa_read
 I²C, 17

orfa_read_reply
 Reply, 15

orfa_set_clock
 SpReq, 22

orfa_set_local
 SpReq, 23

orfa_str_reply_type
 orfa.c, 50
 Reply, 16

orfa_tr_commit
 Transaction, 19

orfa_tr_start
 Transaction, 19

orfa_write

I²C, 17
orfadev, 29
orfadrviers, 32
orfareply, 34
 OR_CLEAR, 35
 OR_CLOCK, 35
 OR_ERROR, 35
 OR_LOCAL, 35
 OR_READ, 35
 OR_VERSION, 35
 OR_WRITE, 35
 orfareply_type, 35
orfareply_type
 orfareply, 35

parser_state
 orfa.h, 40
PBYTE1
 orfa.h, 40
PBYTE1_OR_STOP
 orfa.h, 40
PBYTE2
 orfa.h, 40
PCOMMAND
 orfa.h, 40
PEOL
 orfa.h, 40
PERROR
 orfa.h, 40
prog/lsorfa.c, 70, 71
PSTART
 orfa.h, 40
PSWACK
 orfa.h, 40
PVERSION
 orfa.h, 40

Reply, 15
 orfa_read_reply, 15
 orfa_str_reply_type, 16

Special Requests, 21
SpReq
 orfa_clearbus, 21
 orfa_get_clock, 21
 orfa_get_local, 21
 orfa_get_version, 22
 orfa_set_clock, 22
 orfa_set_local, 23

Transaction
 orfa_tr_commit, 19
 orfa_tr_start, 19